



**Clifford & Snell**

# Wiring Diagrams


Tom Cribb Road, Thamesmead,  
London SE28 0BH  
Tel: +44 (0)20 8316 4477  
or (0)20 8317 1717  
Fax: +44 (0)20 8317 2400  
Email: sales@cliffordandsnell.com  
Web Site: www.cliffordandsnell.com

## TYPICAL CONNECTION DIAGRAMS FOR YODALEX STANDARD TEMP. EXPLOSION PROOF SOUNDER


### MODEL YO9

For other options and full operating and installation instructions see website [www.cliffordandsnell.com](http://www.cliffordandsnell.com)

#### AC ALARM CONNECTIONS AND SOUND SIGNAL SELECTION




#### DC ALARM CONNECTION AND SOUND SIGNAL SELECTION




## TYPICAL CONNECTION DIAGRAMS FOR MANUAL CALL POINTS

### MODELS: - BREAK GLASS, PUSH BUTTON


#### NORMALLY OPEN WITH SERIES MONITORING




#### INTERNAL SWITCH CONNECTIONS ARMED



#### NORMALLY OPEN



#### NORMALLY CLOSED



The Call Point is supplied in two versions: - supplied with or without a monitoring resistor. The version with the monitoring resistor should be connected as shown above. Check panel instructions to ensure the correct value resistor is fitted.

If not required, remove and connect as shown in 'A' or 'B'

Ratings: - Vac: 250V max. / 12 V min. Imax: 5A resistive. Vdc: 30V max. / 12V min.  
Contact resistance: 50 milliohms max. Conductor size: 2.5 sq.mm max. per terminal.

When supplied without the monitoring resistor the Call Point should be connected as shown in 'A' or 'B' above.